



Detailed Instructions and Growing Tips

1. Rinse SEED POD under cold water. Be careful not to let any seeds fall out of the top of the pod. Replace any seeds that fall out by inserting through the top grate of the SEED POD. Place the pod inside the AQUA GARDEN basket by aligning the posts on the bottom of the seed pod with the holes in the bottom of the basket (it should gently snap in place).
2. Snap the AQUA GARDEN on to the rim of your DRINKWELL PET FOUNTAIN. It will hook onto the handle cutout on the side of the fountain bowl (opposite the flow control knob).
3. Within a few days the seeds will germinate and you will begin to see growth. Grass is available to your pets as soon as it grows out of the basket, generally 4-6 days. The AQUA GARDEN does not require direct sunlight. More sunlight will promote faster growth.
4. Your cat(s) can begin to enjoy this natural treat as soon as the blades of grass reach out of the seed pod and basket. Monitor the grass until it becomes "used up" and eaten. A week to two after growth, depending on the number of cats. Remove the unit from the rim of the fountain, turn upside down and squeeze the two prongs of the seed pod toward each other and push the seed pod out of the basket and discard. Rinse the basket and drop in a new seed pod (replacement seed pods are available at your local pet retailer) and replace on the rim of your fountain and you are ready to 'grow' again.

Tips for better growth and a cleaner fountain.

1. Best if used with an Additional Capacity Reservoir. The AQUA GARDEN along with normal evaporation can cause the fountain to use up more water than normal. Use of an Additional Capacity Reservoir will help ensure that your fountain does not run dry.
2. The AQUA GARDEN does not require direct sunlight to grow. However, a moderate amount of light does increase how fast the grass will grow.
3. Trim grass roots as necessary. As the AQUA GARDEN grows you will notice "tiny white hairs" coming out of the bottom of the basket, these are the grass roots. If needed you can remove the AQUA GARDEN from the fountain and trim down the roots with a pair of scissors to prevent them from growing too far outside the unit.
4. Due to the added material in the water (grass seeds, grass and roots) it is important to clean your fountain regularly. You can remove the Aqua Garden and set it on a wet, folded paper towel or in a container with water covering the roots until you return it to the fountain. We recommend cleaning once a week. However, water quality, number of pets using the fountain and other factors play a role in how often YOUR fountain needs to be cleaned. Monitor the condition of the fountain and the water regularly and clean or replace the water as needed.